

Installation Instructions for:
“6 FOOT ADA RECYCLED PLASTIC”
Picnic Table

Parts List: (Quantity for one 6 ft. ADA Picnic Table)

- 2 Bench Slats
- 3 Table Top Supports/Bases
- 3 Table Top Slats
- 2 Base Support Boards (black 2"x4")
- 1 ¾" Round ADA Support Bar
- 1 1 ½" x ½" x 1/8" Channel (ADA Support Bar Mounting Brkt.)
- 5 5/16" x 1 ½" Zinc Plated Hex Lag Screw
- 30 ½" x 4" Zinc Plated Lag Screw
- 6 ¼" x 3 ½" Zinc Plated Lag Screw

Tools Needed for Installation:

- Socket Set with a ¾" & a 7/16" Socket
- 3/8" Drill Bit (Provided)

Installation Instructions:

1. Check Parts list to verify all items.
2. The Picnic Tables have been banded together in sets. Take one set at a time and place the supports on a flat level surface.
3. Attach the two bench slats before putting on the "table tops"
4. Locate the approximate position for the supports to line up with the pre-drilled holes in the bench slats. Put the two bench slats on the supports and position them for final assembly.
5. Be sure that the supports are sitting in the vertical position and that the bench will be assembled "square."
6. Pre-drill the end two holes for the bench slats (with the 3/8" drill bit provided) and attach the bench slats with the ¾" lag screws
7. Drill the center hole on the bench slats and attach with the ¾" lag screws.
8. Determine the spacing for the table tops and attach them to the three supports (Pre-drill with the 3/8" drill bit provided)
9. Attach the base support board to the 45-degree portion on the bottom of the base with the 3 ½" lag screws. The base support boards have been pre-drilled, but it is not necessary to pre-drill the bases.
10. Locate/Position the ADA Support Bar and Mounting Bracket in order to support the additional overhang of the Table Top Slats and secure with the 5/16" x 1 ¼" Lag Screw.

***** IMPORTANT *****

**DO NOT TO OVERTIGHTEN THE LAG SCREWS! THIS MAY CAUSE THE
PLASTIC BENCH SUPPORTS TO STRIP OUT.**