

4 FOOT TRAILSIDE



Base



Hardware



Finished

PARTS LIST: (Quantity for one 4' bench)

QTY	ITEM
4	4" x 4"x 4' Resin Wood Slats
2	Powder Coated Structural Steel Frames
1 bag	Hardware

TOOLS NEEDED FOR INSTALLATION:

9/16" Socket Wrench

INSTALLATION INSTRUCTIONS:

1. Make sure that all parts and hardware have been included.
2. Assemble on a flat, level surface.
3. Line up the bases so that the holes in the base line up with the holes drilled in the slats.
4. Place the bolt through base on the underside of the bench into the slat and hang tighten.
5. Repeat step 3 until all slats have been installed
6. Make sure the bench is squared away before tightening with a socket wrench.



www.jayhawkplastics.com

6 FOOT TRAILSIDE



Base



Hardware



Finished

PARTS LIST: (Quantity for one 6' bench)

QTY	ITEM
4	4" x 4"x 6' Resin Wood Slats
3	Powder Coated Structural Steel Frames
1 bag	Hardware

TOOLS NEEDED FOR INSTALLATION:

9/16" Socket Wrench

INSTALLATION INSTRUCTIONS:

1. Make sure that all parts and hardware have been included.
2. Assemble on a flat, level surface.
3. Line up the bases so that the holes in the base line up with the holes drilled in the slats.
4. Place the bolt through base on the underside of the bench into the slat and hang tighten.
5. Repeat step 3 until all slats have been installed
6. Make sure the bench is squared away before tightening with a socket wrench.



www.jayhawkplastics.com

8 FOOT TRAILSIDE



Base



Hardware



Finished

PARTS LIST: (Quantity for one 8' bench)

QTY	ITEM
4	4" x 4"x 8' Resin Wood Slats
4	Powder Coated Structural Steel Frames
1 bag	Hardware

TOOLS NEEDED FOR INSTALLATION:

9/16" Socket Wrench

INSTALLATION INSTRUCTIONS:

1. Make sure that all parts and hardware have been included.
2. Assemble on a flat, level surface.
3. Line up the bases so that the holes in the base line up with the holes drilled in the slats.
4. Place the bolt through base on the underside of the bench into the slat and hang tighten.
5. Repeat step 3 until all slats have been installed
6. Make sure the bench is squared away before tightening with a socket wrench.



www.jayhawkplastics.com